



## **DECOR WAXES**

### **METALLIC and LIMING WHITE**

Original name: Cere Decorative

## **Product Description**

Beautiful Metallic past Waxes with true metal powder for that extra sparkle to make your piece even more special. You can use the metallic waxes to highlight areas or if you really love sparkle put it all over your furniture.

Apply to ornate carvings and mouldings to enhance texture and detailing, or use with your favourite stencil to create gilded shapes, lines and designs. Create an enchanting sparkling patina on your furniture or any other surface previously painted with our chalk paint Novecento Paint.

Use the White Decor Wax to soften and lighten Novecento Paint colours. It can also be applied directly onto unvarnished wood as a liming wax to create a limed oak look. It will seal and protect furniture and walls painted with Novecento Paint chalk paint or with Marmorino.

## **Use**

Mix well before use and always work at room temperature. If the temperature is low put the wax near an heat source (not on fire!!) to soften it.

On Novecento Paint painted items/surfaces: Once dry, apply a good quantity of decorative wax with a cotton cloth or a paint brush covering the entire surface. Let it sit for 10 minutes and then remove the exceeding wax using a cloth soaked in the Novecento Transparent Solid wax until you get the desired patina. Once the surface is completely dry, polish with the Novecento furniture Brush to make the wax shiny and reflective.

On wrought iron: If the iron is rusty, remove the rust with a steel brush in order to obtain a smoother effect. Anyway, you can apply the decorative wax directly on the rust obtaining a more rustic effect. Follow the same method described previously.

## Use

White Liming Wax: this method is more effective on dark wood, on light wood the effect will results more delicate. Clean the treated surfaces and if necessary sand it with sandpaper. Engrave the already existing veining of the wood with a steel brush to open them more. Apply a good quantity of White Liming Wax on the whole surface. Let it dry for 10 minutes and then remove the exceeding decorative wax with a cotton cloth soaked in the Novecento Tranparent Solid Wax so to keep the white exclusively in the veining. Once the surface is completely dry, polish with the Novecento furniture brush.